# Supercook YUMI Firmware UPDATE (1. – 10.)

1. Logon to supercook,me with your credentials



2. Click on the link "Firmware YUMI", it will get you to another screen


3. Select your serial number and download the file

4. Unzip the file SC350_fw_v022(card)_200807.rar

5. Copy it to the root directory of the SD card

6. Insert the SD card back in the YUMI (golden contact points towards you.

7. Click the Yumi MENU key to get to the MAIN MENU -> Setup

8. GO TO -> Update control module

SUPER COOK

Setup

Date
Time
Standby timer
Screen saver
Language
Speaker volume
Slide show
Calibrate scale
WiFi
Update control module
FW version

9. Warning screen: THE UPDATE WILL TAKE apprx. **15-20 minutes** PLEASE KEEP THE POWER ON AND WAIT THE PROMPT SCREEN

SUPER COOK

The upgrade is in process and will take apprx. 3 minutes.

Please keep the Yumi powered on.

Please wait ...

10.Prompt screen, follow the instructions

SUPER COOK

Upgrade successfully
completed. Please switch
the Supercook on/off before
proceeding.

Enjoy more features with your
updated Yumi.